



This leaflet gives only basic information on how to operate the T2 Taximeter. Its many other functions are detailed in a full manual available on the Aquila Electronics web site at:

[www.aquila-electronics.co.uk](http://www.aquila-electronics.co.uk)

Alternatively, you can contact your local Aquila dealer for assistance.

# Quick Start Guide

## Mk II T2 TAXIMETER

**Aquila Electronics Limited**  
**Stafford · England**

**Telephone: 01785 823635**  
**[www.aquila-electronics.co.uk](http://www.aquila-electronics.co.uk)**

© Aquila Electronics Limited

N00519 Issue 1

## MODES

**STANDBY** Display blank or clock

**FOR HIRE** Available for hire. Roof lamp illuminated <sup>1</sup>.

**HIRED** Charging time/distance

**STOPPED** Charging distance only (for Testing).

## TURNING THE METER ON

In **STANDBY** mode, press **FUNC** to enter **FOR HIRE**

## FUNCTIONS IN FOR HIRE MODE

To go back to **STANDBY**, press **BACK**

To enter the user menus, press **EXTRAS**, then

To move between the user menus, press **EXTRAS**, to enter a menu, press **FUNC**.

To select the charging rate, press **OPT** <sup>2</sup>.

## STARTING THE JOURNEY

In **FOR HIRE** mode, press **FUNC** to enter **HIRED**

## FUNCTIONS IN HIRED MODE

To add extras, press **EXTRAS** <sup>1</sup>.

To change rate, press **OPT** <sup>2</sup>.

To display the speedometer, press **BACK** and hold down for **2** seconds <sup>1</sup>.

To suspend/re-start charging, press **BACK** and release immediately <sup>1</sup>.

## ENDING THE JOURNEY

In **HIRED** mode, press **FUNC** to enter **STOPPED**.

## FUNCTIONS IN STOPPED MODE

To go back to **FOR HIRE** mode, press **FUNC**

To go back to **HIRED** mode, press **BACK** <sup>2</sup>.

To add extras, press **EXTRAS** <sup>2</sup>.

To add the fare and extras together, press the **OPT** button <sup>2</sup>.

To print a receipt, press **OPT** and **FUNC** together

## ENTERING THE TOTALS DISPLAY

Press **EXTRAS** in **STANDBY** or **FOR HIRE** modes, then press **FUNC**.



**tE** = Total Earnings  
**F** = Fares  
**E** = Extras  
**H** = Hirings  
**td** = Total Distance  
**Pd** = Paid Distance  
**Ud** = Unpaid Distance  
**NJ** = 'No Jobs'  
**PU** = Power Ups  
• Press **EXTRAS** to change

**t** = Temporary Totals  
**p** = Permanent Totals  
**L** = Last Journey totals  
• Press **OPT** whilst holding **FUNC** to change

## CLEARING THE TOTALS

Press **BACK** while holding **EXTRAS** down.

## USER MENU ENTRIES

Enter from **FOR HIRE** mode by pressing **EXTRAS**.

### Info Menu

- Serial Number
- Tariff Code
- Software Version
- Time
- Date
- Calibration
- Pulse
- Count
- Speed

### Feature Menu

- Beep On/Off
- Brightness
- Speed Alarms
- Date Stop feature
- Taxi lamps

<sup>1</sup> The availability of these features depends on the programming of your Taximeter.

<sup>2</sup> The selection of rates depends on the tariff programmed into your Taximeter. Some rates may be selected automatically by the Taximeter.